

To reprogram BMW 2-button remote fobs (BMW/GEMEL/Digital Alarm)



- Remove alarm unit from the car.
- Remove upper plastic cover from the alarm unit including the receiver. Locate pink wire inside the cover. Replace cover while making sure the pink wire is sticking out the front of the alarm unit.
- Connect the alarm unit to the testing unit (make sure the testing unit is turned off)
- Strip the end of the pink wire and connect it to one of the ground connections of the central alarm unit connector.
- *BEWARE: by reprogramming an existing or new fob ALL existing codes will be made invalid; make sure all fobs to be used are reprogrammed!*
- Take the 1st fob and press the RED button (check if the alarm is ACTIVATED)
- Take the 2nd fob and press the GREY button (check if alarm is DEACTIVATED)
- Take the 3rd fob and press the RED button.
- If there's a 4th fob press its GREY button. If not press the 3rd fob's GREY button.
- Always make sure that reprogramming ends with DEACTIVATING the alarm unit i.e. pressing a fob's GREY button.
- Remove the pink wire from the ground connection and isolate the pink wire's stripped end.
- Place pink wire within the alarm upper cover and install alarm unit in the car.